



FIBERSPAR ADJUSTABLE OUTHAUL KIT ASSEMBLY INSTRUCTIONS FOR ALL CARBON RACE TAIL

Assembly :

1. Align CL111 clamp about 8 inches back from the farthest aft position you would ever place your 'back' hand while sailing.
2. Insert Aluminum Cleats with teeth facing forward and screw assembly together with Stainless Steel Crown Head Screws.
3. Set up Adjustment Lines per top view drawing. Dead end Adjustment Lines just forward of Clamcleat with a clove hitch knot (or thru Clamcleat with Figure 8 knot) before feeding thru Ronstan Blocks and then Forward into Cleats.
4. Set up Outhaul Line per top view drawing. Attach Outhaul Line to Ronstan Blocks with bowline knot to insure easy removal to feed Outhaul Line thru sail grommet.

Parts List :

<u>Qty</u>	<u>Description</u>
2	Ronstan - Single Block
2	Clamcleat CL111 Clamp to Boom with Rubber Shim and 2 Screws Each
2	Aluminum Cleat to fit with CL 111 Clamp
2	7' Lengths of 7/32" (5mm) Prestretch Marlow Braid Line - Red
1	5' Length of 5/32" (4mm) Prestretch Marlow Braid Line - White

Questions, Comments or Suggestions - feel free to contact us :

Tel : 508-291-2770
Fax : 508-291-2772
Email : info@bicsportna.com

File : U:\users\rickw\word\windsurf\aosrt.doc